



**US Army Corps
of Engineers**
Waterways Experiment
Station

Instruction Report ITL-95-2
September 1995

User's Guide for Computer Program TEMPER (X8305)

by Terry West, Federal Energy Regulatory Commission



Approved For Public Release; Distribution Is Unlimited

19951120 094

DTIC QUALITY INSPECTED 6

The contents of this report are not to be used for advertising, publication, or promotional purposes. Citation of trade names does not constitute an official endorsement or approval of the use of such commercial products.



PRINTED ON RECYCLED PAPER

User's Guide for Computer Program TEMPER (X8305)

by **Terry West**


**Federal Energy Regulatory Commission
Atlanta Regional Office
3125 Presidential Parkway
Suite 300
Atlanta, GA 30340**

Final report

Approved for public release; distribution is unlimited



**US Army Corps
of Engineers**
Waterways Experiment
Station



Waterways Experiment Station Cataloging-in-Publication Data

West, Terry.

User's guide for computer program TEMPER (X8305) / by Terry West ; prepared for U.S. Army Corps of Engineers.

49 p. : ill. ; 28 cm. -- (Instruction report ; ITL-95-2)

Includes bibliographic references.

1. Thermal analysis -- Computer programs. 2. Dams -- Computer programs. 3. Heat -- Computer programs. I. United States. Army. Corps of Engineers. II. U.S. Army Engineer Waterways Experiment Station. III. Information Technology Laboratory (U.S. Army Engineer Waterways Experiment Station) IV. Computer-aided Structural Engineering Project. V. Title. VI. Series: Instruction report (U.S. Army Engineer Waterways Experiment Station) ; ITL-95-2.

TA7 W34i no. ITL-95-2

Contents

Preface	v
Conversion Factors, Non-SI to SI Units of Measurement	vi
1—Introduction	1
Background	1
Limitations	1
Units	2
2—Required Data	3
Air Temperatures	3
Reservoir Water Temperatures	3
Concrete Diffusivity	3
Dam Layout	4
3—Input	8
4—Output	11
Mean Monthly Air Temperatures	11
Elevation and Latitude Corrections	12
Amplitudes of Air Temperatures	12
L1 Values	14
Mean Concrete Temperatures with Air Effects Only	15
Mean Concrete Temperatures with Air and Reservoir Effects Only	16
Effects from Solar Radiation Radiation	17
Mean Concrete Temperatures with Air, Reservoir, and Solar Effects Radiation Effects Included	18
Summary Tables for Temperature Loadings	19
Conclusions	23
References	24
Appendix A: Example Files	A1
SF 298	

Accession For .	
NTIS GRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By _____	
Distribution/ _____	
Availability Codes	
A-1	Avail and/or List Special

Preface

This user's guide documents the computer program TEMPER (X8305). The program can be used to estimate the uniform and linear temperature distributions in arch dams. The program uses the theoretical methods described in "Control of Cracking in Mass Concrete Structures" by the U.S. Department of the Interior, Bureau of Reclamation. The user's guide discusses the limitations of the program, provides a description of the data required to run the program, describes the input and output files, and provides example files.

This user's guide was written by Mr. Terry W. West (formerly of the Jacksonville District) under the direction of the Computer-Aided Structural Engineering (CASE) Arch Dam task group. Task group members during the development of this user's guide were:

Mr. Byron J. Foster	CESAD-EN (Chairman)
Mr. G. Ray Navidi	CEMP-ET (formerly CEORH-ED)
Mr. William K. Wigner	CESAJ-END
Mr. Jerry L. Foster	CECW-ED
Mr. Donald R. Dressler	CECW-ED
Mr. H. Wayne Jones	CEWES-IM-DS (Task Group Coordinator)
Mr. David A. Dollar	Bureau of Reclamation
Mr. Larry K. Nuss	Bureau of Reclamation
Mr. Terry W. West	Federal Energy Regulatory Commission (formerly CESAJ-EN)

The work was accomplished under the general supervision of Dr. N. Radhakrishnan, Director, Information Technology Laboratory (ITL), U.S. Army Engineer Waterways Experiment Station (WES), and under the direct supervision of Mr. H. Wayne Jones, Chief, Computer-Aided Engineering Division (CAED), ITL. The technical monitor for Headquarters, U.S. Army Corps of Engineers, was Mr. Jerry Foster.

At the time of publication of this report, Director of WES was Dr. Robert W. Whalin. Commander was COL Bruce K. Howard, EN.

The contents of this report are not to be used for advertising, publication, or promotional purposes. Citation of trade names does not constitute an official endorsement or approval of the use of such commercial products.

Conversion Factors, Non-SI to SI Units of Measurement

Non-SI units of measurement used in this report can be converted to SI units as follows:

Multiply	By	To Obtain
degrees Fahrenheit	5/9	degrees Celsius or kelvins ¹
feet	0.3048	meters
square feet	0.09290304	square meters

¹ To obtain Celsius (C) temperature readings from Fahrenheit (F) readings, use the following formula: $C = (5/9)(F - 32)$. To obtain kelvin (K) readings, use: $K = (5/9)(F - 32) + 273.15$.

1 Introduction

Background

Computer program TEMPER (X8305) was developed to provide a fast and convenient way of predicting the temperature distributions in an arch dam. The output from TEMPER is designed to provide the temperature loads for use in other programs such as the Arch Dam Stress Analysis System (ADSAS) Program. To estimate the mean concrete temperatures, the TEMPER program uses the theoretical methods described in "Control of Cracking in Mass Concrete Structures" by the U.S. Department of the Interior, Bureau of Reclamation (BOR 1981). In addition, the formats for many of the summary tables produced by TEMPER are fashioned after similar computer programs developed by the BOR.

Limitations

The method of temperature prediction used in TEMPER is based on classical heat flow methods and should not be confused with more sophisticated methods which model transient heat flow. The method used by TEMPER involves determining the range of mean concrete temperatures that a slab of concrete will experience if it is exposed to varying temperatures on its two faces.

TEMPER assumes a linear distribution of temperatures between the upstream and downstream faces. This assumption is generally acceptable for relatively thin arch dams. Concrete dams with relatively thick sections will experience a somewhat different temperature distribution since the interior mass may not respond as quickly to changes in temperature at the faces. Therefore, for gravity dams and thick arch dams, the linear assumptions may not be appropriate, especially during the later phases of the design process.

In addition to the above method limitations, the program is limited to 26 elevations.

Units

The units used in TEMPER are feet and degrees Fahrenheit.

2 Required Data

TEMPER determines average temperature distributions within a dam based on the layout of the dam, the diffusivity of the concrete, and various site-specific conditions. The site conditions include air temperatures, reservoir water temperatures, and solar radiation.

Air Temperatures

Air temperature data needed include the average high and low temperatures for each month and the extreme high and low temperatures ever recorded at the site. If air temperature data for the damsite are not available, then data from the closest National Weather Service (NWS) weather station can be used. The program will adjust the temperature data to account for elevation and latitude differences.

Reservoir Water Temperatures

For existing dams, the average maximum and minimum reservoir water temperatures should be used. For new dams, the temperature can be estimated by performing a detailed thermal stratification study or can be estimated based on measured temperatures at nearby reservoirs. EM 1110-2-2201 (Headquarters, U.S. Army Corps of Engineers 1994) provides additional guidance on how reservoir temperatures can be estimated.

Concrete Diffusivity

Thermal diffusivity can be measured using CRD-C 37 (U.S. Army Engineer Waterways Experiment Station (1949). Since the aggregate has the greatest influence on thermal diffusivity, the tests should be performed using the aggregate proposed for new construction. If test results are not initially available, then typical values can be used. Diffusivity usually ranges between 0.20 and

0.60 ft²/day.¹ Table 1 represents typical values based on severely different types of aggregate.

Table 1 Typical Diffusivity Values for Various Aggregates	
Coarse Aggregate	Diffusivity, ft²/hr
Quartzite	0.058
Limestone	0.051
Dolomite	0.050
Granite	0.043
Rhyolite	0.035
Basalt	0.032

Adapted from American Concrete Institute (ACI) 207.1R (ACI 1994).

Dam Layout

There are several variables needed for each arch elevation to be evaluated. These include the thickness of the dam, the slope of the surface from vertical, the angle between north and the normal to surface, and a terrain factor. The thickness of the dam is the average thickness of the dam from abutment to abutment. The slope and angle to north are needed for three cantilever sections: the crown cantilever and cantilevers near the quarter points of the crest. Figures 1 and 2 demonstrate how the slope and angle are determined. The terrain factor is usually the average value for the three cantilever sections. Figure 3 shows the procedure used to determine the terrain factor for each elevation.

¹ A table of factors for converting non-SI units of measurement to SI is presented on page v.




Figure 1. Measuring the angle between north and the normal to the surface




Figure 2. Determining slope of surface




Figure 3. Procedure for determining terrain factors section taken east-west (looking north)

3 Input

TEMPER prompts the user for the names of the input and output files. Data in the input file should be input according to the following guide. All input is in free field (a comma or at least one blank should separate data items). An example input file is shown in Appendix A.

TITLE

TITLE - any alphanumeric information to identify the problem. (80 characters maximum)

DELEV, DLAT, TELEV, TLAT

DELEV - elevation of the damsite

DLAT - latitude of the damsite

TELEV - elevation of the town or weather station (source) for the air temperatures

TLAT - latitude of the town or weather station (source) for the air temperatures

TOWN

TOWN - name of the town or weather station where the air temperature was measured

STATE

STATE - name of the state where the town or weather station is located

TEMP(I,1), TEMP(I,2)

TEMP(I,1) - average low air temperature for the month (deg-F)

TEMP(I,2) - average high air temperature for the month (deg-F)

Note: Repeat this line of data 12 times, one line of data for each month, beginning with January.

TLOWBC, THIGHBC

TLOWBC - lowest recorded air temperature at the source
THIGHBC - highest recorded air temperature at the source

DIFF, NOELE

DIFF - concrete diffusivity (square feet per hour)
NOELE - number of elevations

ELE(I), THICK(I), WATER(I,1), WATER(I,2)

ELE(I) - elevation
THICK(I) - average concrete thickness for the elevation
WATER(I,1) - maximum water temperature at that elevation
WATER(I,2) - minimum water temperature at that elevation

Note: Repeat this line of data NOELE (number of elevations) times. If the normal water surface is below ELE(I), then enter zero for WATER(I,1). If WATER(I,1) is input as zero, then the effects of water are not included in the calculations at ELE(I).

C(I), AN(I,1), AN(I,2)

C(I) - cantilever number
AN(I,1) - upstream angle to north corresponding to the cantilever (see Figure 1)
AN(I,2) - downstream angle to north corresponding to the cantilever (see Figure 1)

Note: Repeat this line of data for each of the three cantilevers. Angles to north must be between 0 and 180 deg.

TFACT(I), (SLOPE(I,K),K=1,6)

TFACT(I) - terrain factor (see Figure 3)
SLOPE(I,K) - concrete slope from vertical (see Figure 2)

Note: Repeat this line of data NOELE (number of elevations) times. Slopes must be either -1.0 or be between -0.4 and 1.0. Negative slopes indicate either undercutting or overhanging (see Figure 2). If the base of the cantilever is below ELE(I), then enter -1.0 for SLOPE(I,K). If SLOPE(I,K) is input as -1.0, then the effects of solar radiation are not included in the calculations.

GROUT

GROUT - closure temperature (deg-F):

Note: Repeat this line for each grout temperature under consideration.

4 Output

Output is written to a file which can be viewed at the terminal or sent to a printer. The output includes a listing of the input data file; the ambient air temperatures for each month; the base ambient air temperatures; elevation and latitude corrections; amplitudes of air temperatures; concrete temperatures with air effects only, with air and reservoir effects, and with the effects of solar radiation; and the ADSAS temperatures for each month for usual conditions and mean conditions with air on both faces and with air on downstream face and water on upstream face.

The following calculations are used to produce the output file and are based primarily on the theoretical methods used in BOR (1981). Table numbers correspond to those in the example output file (Appendix A).

Mean Monthly Air Temperatures (Table 1 in Appendix A)

The mean monthly air temperature T is assumed to be the average of the minimum and maximum values from the input file, calculated for each month in degrees Fahrenheit as:

$$\frac{T = Temp(1) + Temp(2)}{2.0} \quad (1)$$

where

$Temp(1)$ = minimum ambient air temperature for the month

$Temp(2)$ = maximum ambient air temperature for the month

The mean annual base ambient air temperature is calculated by adding the T values for each month together and dividing by 12 (the number of months in a year).

Elevation and Latitude Corrections (Table 2 in Appendix A)

When air temperature data from a source away from the damsite is used, then a correction must be made to the data. The correction value is based on the difference between the elevation and latitude of the weather station and the damsite. The air temperatures are adjusted by 1 °F for each 250-ft change in elevation and for each 1.4-deg change in latitude.

$$Celev = \frac{Telev - Delev}{250.0} \quad (2)$$

$$Clat = \frac{Tlat - Dlat}{1.4} \quad (3)$$

$$Ctot = Celev + Clat \quad (4)$$

where

Celev = correction factor for elevation

Clat = correction factor for latitude

Telev = elevation of the town (source) for air temperatures

Delev = elevation of the damsite

Tlat = latitude of the town (source) for air temperatures

Dlat = latitude of the damsite

Ctot = total correction

Ctot from Equation 4 is added to the mean base ambient air temperatures at the source to obtain the corrected values for the damsite.

Amplitudes of Air Temperatures (Table 3 in Appendix A)

The amplitudes of air temperatures are calculated as shown below. The annual and daily amplitudes are assumed to be the same for mean and usual weather conditions.

Period	Mean Conditions		Usual Conditions	
	Above Mean	Below Mean	Above Mean	Below Mean
Yearly	$Amp(1,1)$	$Amp(1,2)$	$Amp(1,3)$	$Amp(1,4)$
7-Day	$Amp(2,1)$	$Amp(2,2)$	$Amp(2,3)$	$Amp(2,4)$
Daily	$Amp(3,1)$	$Amp(3,2)$	$Amp(3,3)$	$Amp(3,4)$

where

$$Amp(1,1) = Thmm - Tmean \quad (5)$$

$$Amp(1,2) = Tmean - Tlmm \quad (6)$$

$$Amp(2,1) = 0.0 \quad (7)$$

$$Amp(2,2) = 0.0 \quad (8)$$

$$Amp(3,1) = \frac{Tmindif}{2.0} \quad (9)$$

$$Amp(3,2) = Amp(3,1) \quad (10)$$

$$Amp(1,3) = Amp(1,1) \quad (11)$$

$$Amp(1,4) = Amp(1,2) \quad (12)$$

$$Amp(2,3) = Abs[(Amp(1,1) + Amp(3,1)] - \frac{Thigh + Thmmm}{2.0 - Tmean} \quad (13)$$

$$Amp(2,4) = Abs[(Amp(1,2) + Amp(3,1)] - \frac{Tmean - (Tlow + Tlmmm)}{2.0} \quad (14)$$

$$Amp(3,3) = Amp(3,1) \quad (15)$$

$$Amp(3,4) = Amp(3,1) \quad (16)$$

where

$Thmm$ = Highest mean monthly air temperature recorded at the dam

$Tmean$ = Mean annual base ambient air temperature recorded at the dam

$Tlmm$ = Lowest mean monthly air temperature recorded at the dam

$Tmindif$ = Minimum difference between the mean monthly maximum and the corresponding mean monthly minimum

$Thigh$ = Highest maximum recorded air temperature at the dam

$Thmmm$ = Highest mean monthly maximum recorded at the dam

$Tlow$ = Lowest minimum recorded air temperature at the dam

$Tlmmm$ = Lowest mean monthly minimum recorded at the dam

L1 Values (Table 4 in Appendix A)

As described in EM 1110-2-2201, a correction factor is needed to compute an "effective" slab thickness. This effective thickness is related to the actual thickness of the dam, the diffusivity of the concrete, and the air cycle being utilized--yearly, 7-day, or daily. Once the effective thickness is known, the ratios for each cycle can be obtained based on Figure 11 of BOR (1981). The effective slab thickness $L1$ for each air temperature cycle is obtained at each elevation as follows:

$$\text{Annual: } L1 = \frac{\text{Thick}}{\sqrt{Diff * 8760.0}} \quad (17)$$

$$\text{7-Day: } L1 = \frac{\text{Thick}}{\sqrt{Diff * 168.0}} \quad (18)$$

$$\text{Daily: } L1 = \frac{\text{Thick}}{\sqrt{Diff * 24.0}} \quad (19)$$

where

$Thick$ = thickness of the dam at that elevation

$Diff$ = concrete diffusivity

Mean Concrete Temperatures with Air Effects Only (Table 5 of Appendix A)

For each value of $L1$ shown in Table 4 (in Appendix A), a ratio of the variation of mean concrete temperature to the variation of external temperature is obtained. The ratios R are based on Figure 11 of BOR (1981). The products of these ratios and their respective amplitudes from Equations 5-16 are algebraically added to and subtracted from the mean annual air temperature to obtain mean concrete temperatures for the condition of air on both faces.

For $I = 1$ to the number of elevations

Concrete temperatures, mean conditions:

$$\begin{aligned} \text{Above mean: } \text{Air}(I,1) &= \text{Amp}(1,1) * R(I,1) + \text{Amp}(2,1) * R(I,2) \\ &+ \text{Amp}(3,1) * R(I,3) \end{aligned} \quad (20)$$

$$\begin{aligned} \text{Below mean: } \text{Air}(I,2) &= \text{Amp}(1,2) * R(I,1) + \text{Amp}(2,1) * R(I,2) \\ &+ \text{Amp}(3,2) * R(I,3) \end{aligned} \quad (21)$$

$$\text{Maximum: } \text{Air}(I,3) = \text{Tmean} + \text{Air}(I,1) \quad (22)$$

$$\text{Minimum: } \text{Air}(I,4) = \text{Tmean} - \text{Air}(I,2) \quad (23)$$

Concrete temperatures, usual conditions:

$$\begin{aligned} \text{Above mean: } \text{Air}(I,5) &= \text{Amp}(1,3) * R(I,1) + \text{Amp}(2,3) * R(I,2) \\ &+ \text{Amp}(3,3) * R(I,3) \end{aligned} \quad (24)$$

$$\begin{aligned} \text{Below mean: } \text{Air}(I,6) &= \text{Amp}(1,4) * R(I,1) + \text{Amp}(2,4) * R(I,2) \\ &+ \text{Amp}(3,4) * R(I,3) \end{aligned} \quad (25)$$

$$\text{Maximum: } \text{Air}(I,7) = \text{Tmean} + \text{Air}(I,5) \quad (26)$$

$$\text{Minimum: } \text{Air}(I,8) = \text{Tmean} - \text{Air}(I,6) \quad (27)$$

Mean Concrete Temperatures with Air and Reservoir Effects Only (Table 6 in Appendix A)

Mean concrete temperatures which would result from a fictitious condition of water on both faces are then obtained, and the two conditions (air only and water only) are simply averaged together to obtain the condition of air on the downstream face and water on the upstream face.

For $I = 1$ to the number of elevations

Water temperatures:

Maximum : Water(I,1)

Minimum : Water(I,2)

$$\text{Average : Water}(I,3) = \frac{\text{Water}(I,1) + \text{Water}(I,2)}{2.0} \quad (28)$$

$$\text{Amplitude : Water}(I,4) = \text{Water}(I,1) - \text{Water}(I,3) \quad (29)$$

Concrete temperatures with water on both sides:

$$\text{Amplitude : Water}(I,5) = \text{Water}(I,4) * \text{Yratio} \quad (30)$$

$$\text{Maximum : Water}(I,6) = \text{Water}(I,3) + \text{Water}(I,5) \quad (31)$$

$$\text{Minimum : Water}(I,7) = \text{Water}(I,3) - \text{Water}(I,5) \quad (32)$$

where

Water (I,1) = maximum water temperature input to the data file

Water (I,2) = minimum water temperature input to the data file

Yratio = yearly ratio for a flat slab for each elevation

Concrete temperatures with air on downstream face and water on upstream face:

$$\text{Mean maximum : Combo}(I,1) = \frac{\text{Air}(I,3) + \text{Water}(I,6)}{2.0} \quad (33)$$

$$\text{Mean minimum : } \text{Combo}(I,2) = \frac{\text{Air}(I,4) + \text{Water}(I,7)}{2.0} \quad (34)$$

$$\text{Usual maximum : } \text{Combo}(I,3) = \frac{\text{Air}(I,7) + \text{Water}(I,6)}{2.0} \quad (35)$$

$$\text{Usual minimum : } \text{Combo}(I,4) = \frac{\text{Air}(I,8) + \text{Water}(I,7)}{2.0} \quad (36)$$

Effects from Solar Radiation (Table 7 in Appendix A)

The mean concrete temperatures obtained from air and water temperatures require adjustments due to the effect of solar radiation on the surface of the dam. Theoretical studies have been made which take into consideration varying slopes, orientation of the exposed faces, and latitudes. The results of these studies are presented in an unpublished BOR memorandum.¹ Figures 25-29 in BOR (1981) summarize the results and give values of the temperature increase. These curves are included in the program and used to determine the increase in temperature due to solar radiation T_{solar} . These temperature rises are then corrected by the terrain factor T_{fact} which is input and is expressed as the ratio of actual exposure to the sun's rays to the theoretical exposure.

For each elevation I and $K = 1$ to 6

$$Asolar(I,K) = \frac{T_{fact}(I) * T_{solar}(I,K)}{100.0} \quad (37)$$

where

$T_{fact}(I)$ = terrain factor input in the data file

$T_{solar}(I,K)$ = temperature increase due to sun

The calculation in Equation 37 is made for the right side, the crown, and the left side cantilevers. Then the average temperature increases due to solar radiation are calculated for each elevation for the upstream (U.S.) face, the downstream (D.S.) face, the average of the upstream and downstream, and half of the downstream as:

¹ W. A. Trimble. (1954). "The average temperature rise of the surface of a concrete dam due to solar radiation," Bureau of Reclamation, unpublished, Denver, CO.

$$U.S.: \ Solar(I,1) = \frac{Asolar(I,1) + Asolar(I,3) + Asolar(I,5)}{N} \quad (38)$$

$$D.S.: \ Solar(I,2) = \frac{Asolar(I,2) + Asolar(I,4) + Asolar(I,6)}{N} \quad (39)$$

$$Avg.: \ Solar(I,3) = \frac{Solar(I,1) + Solar(I,2)}{2.0} \quad (40)$$

$$D.S./2: \ Solar(I,4) = \frac{Solar(I,2)}{2.0} \quad (41)$$

where N = number of $Asolar(I)$'s not equal to zero in the equation.

Mean Concrete Temperatures with Air, Reservoir, and Solar Radiation Effects Included (Table 8 in Appendix A)

The mean concrete temperatures that were calculated from Equations 22, 23, 26, and 27 for the conditions of air on both sides and air on the downstream face and water on the upstream face are increased by the $Solar(I,K)$'s from Equations 40 and 41 to produce the mean concrete temperatures with air, reservoir, and solar radiation effects included.

For $I = 1$ to the number of elevations

Mean concrete temperatures with air on both faces:

Mean conditions:

$$Maximum: \ Conc(I,1) = Air(I,3) + Solar(I,3) \quad (42)$$

$$Minimum: \ Conc(I,2) = Air(I,4) + Solar(I,3) \quad (43)$$

Usual conditions:

$$Maximum: \ Conc(I,3) = Air(I,7) + Solar(I,3) \quad (44)$$

$$Minimum: \ Conc(I,4) = Air(I,8) + Solar(I,3) \quad (45)$$

Mean concrete temperatures with air on downstream face and water on upstream face:

Mean conditions:

$$\text{Maximum: } \text{Conc}(I,5) = \text{Combo}(I,1) + \text{Solar}(I,N) \quad (46)$$

$$\text{Minimum: } \text{Conc}(I,6) = \text{Combo}(I,2) + \text{Solar}(I,N) \quad (47)$$

Usual conditions:

$$\text{Maximum: } \text{Conc}(I,7) = \text{Combo}(I,3) + \text{Solar}(I,N) \quad (48)$$

$$\text{Minimum: } \text{Conc}(I,8) = \text{Combo}(I,4) + \text{Solar}(I,N) \quad (49)$$

where $N = 4$

or $= 3$ if $\text{Water}(I,1) = 0.0$ in the data input.

Summary Tables for Temperature Loadings

The remaining tables in the TEMPER output file consist of a series of tables which convert the mean concrete temperatures into a format which can be used directly as temperature loads for the ADSAS computer program. A separate set of five tables is produced for each closure temperature specified by the user in the input file. The first set of tables (Tables 9-1 through 9-5) provides the ADSAS temperature loads for the first closure temperature in the data file. If there is a second closure temperature specified, then Tables 10-1 through 10-5 are printed. This procedure is continued for each closure temperature. The discussions below for Tables 9-1 through 9-5 are applicable to all the remaining tables.

ADSAS temperature for loadings (02) and (03) (Table 9-1 In Appendix A)

ADSAS uses uniform and linear temperature loads in the determination of stresses in an arch dam. Uniform temperature loads are called "02" in ADSAS terminology. The uniform temperature load is the difference between the computed mean concrete temperature and the assumed closure (grout) temperature.

The uniform ADSAS temperature for loading (02) with air on the downstream face and water on the upstream face is calculated for each elevation as:

For $I = 1$ to the number of elevations

Mean conditions:

$$\text{Maximum: } Adsas(I,2) = Conc(I,5) - Grout \quad (50)$$

$$\text{Minimum: } Adsas(I,3) = Conc(I,6) - Grout \quad (51)$$

Usual conditions:

$$\text{Maximum: } Adsas(I,4) = Conc(I,7) - Grout \quad (52)$$

$$\text{Minimum: } Adsas(I,5) = Conc(I,8) - Grout \quad (53)$$

where *Grout* = closure temperature.

The linear temperature loads are called "03" loads in ADSAS terminology. The linear temperature is the difference between the face temperatures in degrees Fahrenheit from the straight line approximation used to determine the uniform temperature loads (02).

The linear ADSAS temperature for loading (03) with air on the downstream face and water on the upstream face is calculated as:

For $I = 1$ to the number of elevations

If *Water* ($I,6$) is greater than zero:

Mean conditions:

$$\text{Maximum: } Adsas(I,6) = Conc(I,1) - Water(I,6) \quad (54)$$

$$\text{Minimum: } Adsas(I,7) = Conc(I,2) - Water(I,7) \quad (55)$$

Usual conditions:

$$\text{Maximum: } Adsas(I,8) = Conc(I,3) - Water(I,6) \quad (56)$$

$$\text{Minimum: } Adsas(I,9) = Conc(I,4) - Water(I,7) \quad (57)$$

If *Water* ($I,6$) is zero:

Mean conditions:

$$\text{Maximum: } Adsas(I,6) = Solar(I,2) - Solar(I,1) \quad (58)$$

$$\text{Minimum: } Adsas(I,7) = Solar(I,2) - Solar(I,1) \quad (59)$$

Usual conditions:

$$\text{Maximum: } \text{Adsas}(I,8) = \text{Solar}(I,2) - \text{Solar}(I,1) \quad (60)$$

$$\text{Minimum: } \text{Adsas}(I,9) = \text{Solar}(I,2) - \text{Solar}(I,1) \quad (61)$$

The uniform ADSAS temperature for loading (02) with air on both faces is calculated for each elevation as:

For $I = 1$ to the number of elevations

Mean conditions:

$$\text{Maximum: } \text{Adsas}(I,10) = \text{Conc}(I,1) - \text{Grout} \quad (62)$$

$$\text{Minimum: } \text{Adsas}(I,11) = \text{Conc}(I,2) - \text{Grout} \quad (63)$$

Usual conditions:

$$\text{Maximum: } \text{Adsas}(I,12) = \text{Conc}(I,3) - \text{Grout} \quad (64)$$

$$\text{Minimum: } \text{Adsas}(I,13) = \text{Conc}(I,4) - \text{Grout} \quad (65)$$

where Grout = closure temperature.

The linear ADSAS temperature for loading (03) with air on both faces is calculated as:

$$\text{Adsas}(I,14) = \text{Solar}(I,2) - \text{Solar}(I,1) \quad (66)$$

ADSAS temperature input by month (Tables 9-2 through 9-5 in Appendix A)

Tables 9-2 through 9-5 are included since loading combinations for arch dams are usually based on specified reservoir elevations and concurrent concrete temperatures (reference 4-1 in EM 1110-2-2201).

The ADSAS temperatures calculated by Equations 50-66 are used to calculate the temperatures for each month of the year. The program assumes the lowest concrete temperatures occur in February and the highest concrete temperatures occur in August.

Table 9-2. Usual conditions with air downstream face/water upstream face. This table is normally used in conjunction with the static usual (SU) loading conditions described in Chapter 4 of EM 1110-2-2201. The temperatures are calculated as:

For $I = 1$ to $Noele$ (number of elevations) and $J = 1$ to 12 (number of months in a year)

$$\begin{aligned} \text{Uniform: } T_{montu}(I,J) &= Adsas(I,5) + [Adsas(I,4) - Adsas(I,5)] \\ &\quad * \frac{6.0 - Rf(J)}{6.0} \end{aligned} \quad (68)$$

$$\begin{aligned} \text{Linear: } T_{montl}(I,J) &= Adsas(I,9) + [Adsas(I,8) - Adsas(I,9)] \\ &\quad * \frac{6.0 - Rf(J)}{6.0} \end{aligned} \quad (69)$$

where $Rf(J)$ = factor for adjusting the temperature from high and low to monthly assuming August is the hottest month and February is the coldest month.

Table 9-3. Usual conditions with air on both faces. This table is not normally used, but can be used in the end of construction condition (SUN3) if a more severe temperature load than that shown in Table 9-5 is desired. The temperatures are calculated as:

For $I = 1$ to $Noele$ (number of elevations) and $J = 1$ to 12 (number of months in a year)

$$\begin{aligned} \text{Uniform: } T_{montu}(I,J) &= Adsas(I,13) + [Adsas(I,12) - Adsas(I,13)] \\ &\quad * \frac{6.0 - Rf(J)}{6.0} \end{aligned} \quad (70)$$

$$\text{Linear: } T_{montl}(I,J) = Adsas(I,14) \quad (71)$$

Table 9-4. Mean conditions with air downstream face/water upstream face. This table is normally used in conjunction with the static unusual (SUN), static extreme (SE), and each of the dynamic loading conditions, with the exception of the end of construction condition (SUN3). The temperatures are calculated as:

For $I = 1$ to $Noele$ (number of elevations) and $J = 1$ to 12 (number of months in a year)

$$\begin{aligned} \text{Uniform: } T_{montu}(I,J) &= Adsas(I,3) + [Adsas(I,2) - Adsas(I,3)] \\ &\quad * \frac{6.0 - Rf(J)}{6.0} \end{aligned} \quad (72)$$

$$\begin{aligned} \text{Linear: } T_{montl}(I,J) &= Adsas(I,7) + [Adsas(I,6) - Adsas(I,7)] \\ &\quad * \frac{6.0 - Rf(J)}{6.0} \end{aligned} \quad (73)$$

Table 9-5. Mean conditions with air on both faces. This table is normally used in conjunction with the end of construction condition (SUN3). The temperatures are calculated as:

For $I = 1$ to $Noele$ (number of elevations) and $J = 1$ to 12 (number of months in a year)

$$\begin{aligned} \text{Uniform: } T_{montu}(I,J) &= Adsas(I,11) + [Adsas(I,10) - Adsas(I,11)] \\ &\quad * \frac{6.0 - Rf(J)}{6.0} \end{aligned} \quad (74)$$

$$\text{Linear: } T_{montl}(I,J) = Adsas(I,14) \quad (75)$$

Conclusions

Computer program TEMPER (X8305) provides a quick way of predicting the uniform and linear temperature distributions in an arch dam. These temperature distributions are for use in other programs such as the Arch Dam Stress Analysis System Program which is used to predict the behavior of arch dams. To estimate these concrete temperatures, the TEMPER program uses the theoretical methods described in "Control of Cracking in Mass Concrete Structures" by the U. S. Department of the Interior, Bureau of Reclamation (BOR 1981).

References

American Concrete Institute. (1994). "Mass concrete," ACI 207.1R-87, Detroit, MI.

Bureau of Reclamation. (1981). "Control of cracking in mass concrete structures," Engineering Monograph 34 (EM34), revised reprint Denver, CO.

Headquarters, U.S. Army Corps of Engineers (1994). "Design of arch dams," EM 1110-2-2201, Washington, DC.

U.S. Army Engineer Waterways Experiment Station. (1949). "Method of test for thermal diffusivity of mass concrete," CRD-C 37, *Handbook for concrete and cement*, Vicksburg, MS.

Appendix A

Example Files

Example Data File

HAYSI PRELIMINARY W.S. EL. 1361
1255.0, 37.17, 2504.0, 37.76
BECKLEY
WEST VIRGINIA

22.50	36.70
25.60	41.20
31.70	53.40
38.60	56.50
52.90	75.70
58.80	78.80
62.00	83.30
61.60	83.90
55.20	72.80
36.80	60.00
36.90	55.80
29.80	45.30
-3.0	93.00
0.25	8
1470.0	10.0
1435.0	18.3
1405.0	23.7
1375.0	28.1
1335.0	30.5
1315.0	32.2
1285.0	32.7
1255.0	32.0
17.9.0	171.0
20.36.0	144.0
23.58.5	121.5
90.0	0.0
88.9	-217
87.2	-126
84.2	-006
81.1	-112
78.8	-218
75.3	-1.0
71.9	-1.0
45.0	
50.0	

```
*****
* * * * * Example Output File
* * * * *
* * * * * ECHO FROM DATA FILE
* * * * *
*****
```

CARD	1	HAYSI PRELIMINARY W.S. EL. 1361	
CARD	2	1255.0, 37.17, 2504.0, 37.76	
CARD	3	BECKLEY	
CARD	4	WEST VIRGINIA	
CARD	5	22.50	36.70
CARD	6	25.60	41.20
CARD	7	31.70	53.40
CARD	8	38.60	56.50
CARD	9	52.90	75.70
CARD	10	58.80	78.80
CARD	11	62.00	83.30
CARD	12	61.60	83.90
CARD	13	55.20	72.80
CARD	14	36.80	60.00
CARD	15	36.90	55.80
CARD	16	29.80	45.30
CARD	17	-3.00	93.00
CARD	18	-025	8
CARD	19	1470.0	10.0
CARD	20	1435.0	18.3
CARD	21	1405.0	23.7
CARD	22	1375.0	28.1
CARD	23	1345.0	30.5
CARD	24	1315.0	32.2
CARD	25	1285.0	32.7
CARD	26	1255.0	32.0
CARD	27	117	9.0
CARD	28	20	36.0
CARD	29	23	58.5
CARD	30	90.0	0.0
CARD	31	88.9	-212
CARD	32	87.2	-126
CARD	33	84.2	-006
CARD	34	81.1	-112
CARD	35	78.8	-218
CARD	36	75.5	-210
CARD	37	71.9	-1.0
CARD	38	50.0	0.0

TABLE 1
MEAN MONTHLY AIR TEMPERATURES IN DEGREES FAHRENHEIT
MEASURED AT: TOWN - BECKLEY
STATE - WEST VIRGINIA
EL. 2504.00 LAT. 37.76N

MONTH	MIN	MEAN	MAX
JAN	22.50	29.60	36.70
FEB	25.60	33.40	41.20
MAR	31.70	42.55	53.40
APR	38.60	47.55	56.50
MAY	52.90	64.30	75.70
JUN	58.80	68.80	78.80
JUL	62.00	72.65	83.30
AUG	61.60	72.75	83.90
SEP	55.20	64.00	72.80
OCT	36.80	48.40	60.10
NOV	36.90	46.35	55.80
DEC	29.80	37.55	45.30

TABLE 2
BASE AMBIENT AIR TEMPERATURES IN DEGREES FAHRENHEIT
CORRECTED FOR ELEVATION AND LATITUDE

SOURCE	CORRECTED
MEAN ANNUAL	52.32
HIGH MEAN MONTHLY	57.74
LOW MEAN MONTHLY	72.75
HIGHEST MEAN MONTHLY MAXIMUM	78.17
LOWEST MEAN MONTHLY MINIMUM	35.02
LOWEST MINIMUM	29.60
HIGHEST MAXIMUM	83.90
LOWEST DIFFERENCE BETWEEN MEAN MONTHLY	89.32
MAXIMUM AND MEAN MONTHLY MINIMUM	22.50
ELEVATION AND LATITUDE CORRECTION BETWEEN SITE AND SOURCE	27.92
SITE EL. 1255.00 ; CORRECTION 5.00 (1 DEG / 250 FT)	-3.00
SITE LAT. 37.17N; CORRECTION .42 (1 DEG / 1.4 LAT)	2.42
TOTAL CORRECTION = 5.42 DEGREES	98.42
	14.20
	14.20

TABLE 3
AMPLITUDES OF AIR TEMPERATURES
(SEE TABLE II ON PAGE 19 OF BUREAU OF RECLAMATION
ENGINEERING MONOGRAPH NO. 34 FOR EQUATIONS)

PERIOD	MEAN CONDITIONS		USUAL CONDITIONS	
	ABOVE MEAN	BELOW MEAN	ABOVE MEAN	BELOW MEAN
YEARLY	20.425	22.725	20.425	22.725
7-DAY	.000	.000	8.600	12.750
DAILY	7.100	7.100	7.100	7.100

TABLE 4
L1 VALUES USED TO DETERMINE THE YEARLY, 7-DAY, AND DAILY RATIOS SHOWN IN TABLE 5
BASED ON A CONCRETE DIFFUSIVITY OF .025 SQ FT PER HOUR
(NOTE: RATIOS OBTAINED FROM FIGURE 11 OF BUREAU OF RECLAMATION MONOGRAPH NO. 34)

ELEV.	YEARLY L1 VALUE	7-DAY L1 VALUE	DAILY L1 VALUE					
				1	2	3	4	5
1 1470.0	.7	4.9	12.9					
2 1435.0	1.2	8.9	23.6					
3 1405.0	1.6	11.6	30.6					
4 1375.0	1.9	13.7	36.3					
5 1345.0	2.1	14.9	39.4					
6 1315.0	2.2	15.7	41.6					
7 1285.0	2.2	16.0	42.2					
8 1255.0	2.2	15.6	41.3					

TABLE 5
CONCRETE TEMPERATURE BASED ON AIR EFFECTS ONLY
(NO RESERVOIR AND SOLAR RADIATION EFFECTS)

ELEV.	THICK.	YEARLY RATIO	7-DAY DAILY RATIO	MEAN CONDITIONS				AIR ON BOTH FACES ONLY USUAL CONDITIONS			
				ABOVE MEAN	BELOW MEAN	MAX	MIN	ABOVE MEAN	BELOW MEAN	MAX	MIN
1 1470.0	10.0	.956	.164	.062	19.96	22.16	77.70	35.58	21.37	79.11	33.49
2 1435.0	18.3	.737	.090	.034	15.30	17.00	73.04	40.74	16.07	78.14	39.60
3 1405.0	23.7	.560	.069	.026	11.63	12.92	69.37	44.82	12.23	73.80	43.94
4 1375.0	28.1	.435	.058	.022	9.03	10.03	66.78	47.71	9.54	70.78	46.96
5 1345.0	30.5	.388	.054	.020	8.07	8.97	65.81	48.78	8.53	69.65	48.09
6 1315.0	32.2	.368	.051	.019	7.65	8.49	65.39	49.25	8.08	70.14	48.60
7 1285.0	32.7	.362	.050	.019	7.53	8.36	65.27	49.38	7.96	9.00	65.70
8 1255.0	32.0	.370	.051	.019	7.69	8.54	65.44	49.20	8.13	9.20	65.88

TABLE 6
CONCRETE TEMPERATURE WITH AIR AND RESERVOIR EFFECTS
(NO SOLAR RADIATION EFFECTS)

ELEV.	WATER TEMPERATURE				WATER ON BOTH SIDES				AIR ON D.S. FACE WATER ON U.S. FACE			
	MAX	MIN	AVG	AMP	MAX	AMP	MIN	MEAN	MAX	MIN	MAX	MIN
1 1470.0									77.7	79.1	35.6	33.5
2 1435.0									73.0	73.8	40.7	39.6
3 1405.0									69.4	70.0	44.8	43.9
4 1375.0									66.8	67.3	47.7	47.0
5 1345.0	80.00	35.00	57.50	22.50	8.73	66.23	48.77	66.0	48.8	66.3	48.4	
6 1315.0	65.00	39.00	52.00	13.00	4.78	56.78	47.22	61.1	48.2	61.3	47.9	
7 1285.0	63.00	39.00	51.00	12.00	4.34	55.34	46.66	60.3	48.0	60.5	47.7	
8 1255.0	61.00	39.00	50.00	11.00	4.07	54.07	45.93	59.8	47.6	60.0	47.2	

TABLE 7
CALCULATE THE EFFECTS OF SOLAR RADIATION

CANTILEVER 17		UPSTREAM			DOWNSTREAM		
ELEV.	TF	ANGLE TO NORTH =	9.0	ANGLE TO NORTH = 171.0			
		SLOPE	100%	ACTUAL	SLOPE	100%	ACTUAL
1	1470.0	90.0	.000	.9	.000	7.3	6.6
2	1435.0	88.9	.217	1.2	.018	7.2	6.4
3	1405.0	87.2	.126	1.1	.042	7.7	6.7
4	1375.0	84.2	-.006	.9	.164	8.8	7.4
5	1345.0	81.1	-.112	.8	.328	10.1	8.2
6	1315.0	78.8	-.218	.7	.385	10.4	8.2
7	1285.0	75.3					
8	1255.0	71.9					

CANTILEVER 20		UPSTREAM			DOWNSTREAM		
ELEV.	TF	ANGLE TO NORTH =	36.0	ANGLE TO NORTH = 144.0			
		SLOPE	100%	ACTUAL	SLOPE	100%	ACTUAL
1	1470.0	90.0	.000	2.0	1.8	.000	7.3
2	1435.0	88.9	.393	3.2	2.8	.193	5.8
3	1405.0	87.2	.310	2.9	2.5	.142	6.2
4	1375.0	84.2	-.177	2.4	2.1	-.054	6.8
5	1345.0	81.1	-.052	2.1	1.7	.032	7.5
6	1315.0	78.8	-.071	1.8	1.5	.119	8.3
7	1285.0	75.3	.000	2.0	1.5	.209	9.0
8	1255.0	71.9	.000	2.0	1.4	.295	6.8

TABLE 7 (continued)
CALCULATE THE EFFECTS OF SOLAR RADIATION

CANTILEVER	23	UPSTREAM			DOWNSTREAM					
		ANGLE TO NORTH =	58.5	ANGLE TO NORTH = 121.5	SLOPE	100%	ACTUAL	SLOPE	100%	ACTUAL
1	1470.0	90.0	.000	3.5	3.2	3.8	7.0	.000	6.3	6.3
2	1435.0	88.9	.203	4.3	4.0	3.5	6.9	-.004	6.2	6.2
3	1405.0	87.2	.112	4.0	3.4	3.5	7.3	-.056	6.4	6.4
4	1375.0	84.2	-.020	3.4	2.9	2.9	8.2	-.181	6.9	6.9
5	1345.0	81.1	-.125	3.1	2.5	2.5	9.1	-.351	7.4	7.4
6	1315.0	78.8	-.229	2.7	2.2	2.2	9.4	.405	7.4	7.4
7	1285.0	75.3								
8	1255.0	71.9								

ELEV.	SUMMARY OF SOLAR RADIATION EFFECTS			D.S./2
	U.S.	D.S.	Avg.	
1 1470.0	1.9	6.5	4.2	3.2
2 1435.0	2.9	5.9	4.2	2.9
3 1405.0	2.3	6.2	4.2	3.1
4 1375.0	1.9	6.7	4.3	3.3
5 1345.0	1.6	7.2	4.4	3.6
6 1315.0	1.4	7.4	4.4	3.7
7 1285.0	1.5	6.8	4.1	3.4
8 1255.0	1.4	6.8	4.1	3.4

TABLE 8
MEAN CONCRETE TEMPERATURES WITH AIR, RESERVOIR, AND SOLAR RADIATION EFFECTS INCLUDED

ELEV.	THICK.	AIR ON BOTH FACES			AIR ON D.S. FACE WATER ON U.S. FACE		
		MEAN		USUAL	MEAN		USUAL
		MAX.	MIN.	MAX.	MIN.	MAX.	MIN.
1 1470.0	10.0	81.9	39.8	83.3	37.7	81.9	39.8
2 1435.0	18.3	77.3	45.0	78.0	43.8	77.3	45.0
3 1405.0	23.7	73.6	49.1	74.2	48.2	73.6	49.1
4 1375.0	28.1	71.1	52.0	71.6	51.3	71.1	52.0
5 1345.0	30.5	70.2	53.2	70.7	52.5	69.6	52.4
6 1315.0	32.2	69.8	53.6	70.2	53.0	64.8	51.9
7 1285.0	32.7	69.4	53.5	69.8	52.9	63.7	51.4
8 1255.0	32.0	69.6	53.3	70.0	52.7	63.2	51.0

TABLE 9-1
ADSA'S TEMPERATURE INPUT FOR (03) AND (02) LOADING - CLOSURE TEMPERATURE = 45.0 F

ELEV	MEAN COND	USUAL COND			MEAN COND			USUAL COND			MEAN COND			USUAL COND			TO AIR ON EXPOSED FACES			TO AIR ON EXPOSED FACES			
		MAX	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX	
1470.00	36.89	-5.23	38.30	-7.33	4.55	4.55	4.55	4.55	36.89	-5.23	38.30	-7.33	38.30	-5.23	38.30	-7.33	38.30	-5.23	38.30	-7.33	38.30	-5.23	4.55
1435.00	32.28	-0.02	33.05	-1.16	3.31	3.31	3.31	3.31	32.28	-0.02	33.05	-1.16	32.28	-0.02	33.05	-1.16	32.28	-0.02	33.05	-1.16	32.28	-0.02	3.31
1405.00	28.61	4.06	29.21	3.18	3.87	3.87	3.87	3.87	28.61	4.06	29.21	3.18	28.61	4.06	29.21	3.18	28.61	4.06	29.21	3.18	28.61	4.06	3.87
1375.00	26.07	7.00	26.57	6.26	4.80	4.80	4.80	4.80	26.07	7.00	26.57	6.26	26.07	7.00	26.57	6.26	26.07	7.00	26.57	6.26	26.07	7.00	4.80
1345.00	24.64	7.38	24.87	7.04	4.00	4.43	4.46	4.46	24.64	7.38	24.87	7.04	24.64	7.38	24.87	7.04	24.64	7.38	24.87	7.04	24.64	7.38	5.62
1315.00	19.77	6.92	19.99	6.60	12.99	6.41	13.42	5.76	24.77	8.63	25.20	7.98	24.77	8.63	25.20	7.98	24.77	8.63	25.20	7.98	24.77	8.63	5.98
1285.00	18.69	6.40	18.91	6.08	14.05	6.85	14.49	6.21	24.40	8.51	24.83	7.87	24.40	8.51	24.83	7.87	24.40	8.51	24.83	7.87	24.40	8.51	5.28
1255.00	18.17	5.98	18.39	5.65	15.49	7.39	15.93	6.74	24.56	8.32	25.00	7.67	24.56	8.32	25.00	7.67	24.56	8.32	25.00	7.67	24.56	8.32	5.41

***** WARNING *****
THESE TABLES ASSUME THE LOWEST CONCRETE TEMPERATURES OCCUR IN FEBRUARY AND THE HIGHEST CONCRETE TEMPERATURES OCCUR IN AUGUST. SOME ADJUSTMENTS MAY BE NECESSARY BASED UPON "SITE SPECIFIC" CONDITIONS.

TABLE 9-2
ADSAS TEMPERATURE INPUT BY MONTH USUAL CONDITIONS, AIR DS FACE / WATER US FACE CLOSURE TEMPERATURE = 45.0 F

ELEV	JAN	FEB	MAR	APR	MAY	JUN						
	AVG AIR = 35.0 F: AVG AIR = 38.8 F:	AVG AIR = 48.0 F: AVG AIR = 48.0 F:	AVG AIR = 53.0 F: AVG AIR = 53.0 F:	AVG AIR = 59.7 F: AVG AIR = 59.7 F:	AVG AIR = 69.7 F: AVG AIR = 69.7 F:	AVG AIR = 74.2 F: AVG AIR = 74.2 F:						
:UNIFORM : LINEAR												
1470.00:	-2.8	4.55	-7.33	4.55	-2.8	4.55	-7.88	4.55	-15.49	4.55	-23.09	4.55
1435.00:	4.54	3.31	-1.16	3.31	4.54	3.31	10.24	3.31	15.94	3.31	21.64	3.31
1405.00:	7.52	3.87	3.18	3.87	7.52	3.18	11.85	3.87	16.19	3.87	20.53	3.87
1375.00:	9.65	4.80	6.26	4.80	9.65	4.80	13.03	4.80	16.42	4.80	19.80	4.80
1345.00:	10.01	3.86	7.04	3.74	10.01	3.86	12.98	3.98	15.95	4.10	18.93	4.22
1315.00:	8.83	7.04	6.60	5.76	8.83	7.04	11.06	8.31	13.29	9.59	15.52	10.87
1285.00:	8.22	7.59	6.08	6.21	8.22	7.59	10.36	8.97	12.49	10.35	14.63	11.73
1255.00:	7.77	8.27	5.65	6.74	7.77	8.27	9.90	9.80	12.02	11.33	14.14	12.87

TABLE 9-2
ADSAS TEMPERATURE INPUT BY MONTH USUAL CONDITIONS, AIR DS FACE / WATER US FACE CLOSURE TEMPERATURE = 45.0 F

ELEV	JUL	AUG	SEP	OCT	NOV	DEC						
	AVG AIR = 78.1 F: AVG AIR = 78.2 F: AVG AIR = 69.4 F: AVG AIR = 53.8 F: AVG AIR = 51.8 F: AVG AIR = 49.0 F:	AVG AIR = 78.2 F: AVG AIR = 78.2 F: AVG AIR = 69.4 F: AVG AIR = 53.8 F: AVG AIR = 51.8 F: AVG AIR = 49.0 F:	AVG AIR = 69.4 F: AVG AIR = 53.8 F: AVG AIR = 51.8 F: AVG AIR = 49.0 F: AVG AIR = 49.0 F: AVG AIR = 49.0 F:	AVG AIR = 53.8 F: AVG AIR = 51.8 F: AVG AIR = 49.0 F:	AVG AIR = 51.8 F: AVG AIR = 49.0 F:	AVG AIR = 49.0 F:						
:UNIFORM : LINEAR												
1470.00:	30.69	4.55	38.30	4.55	30.69	4.55	23.09	4.55	15.49	4.55	7.88	4.55
1435.00:	27.35	3.31	33.05	3.31	27.35	3.31	21.64	3.31	15.94	3.31	10.24	3.31
1405.00:	24.87	3.87	29.21	3.87	24.87	3.87	20.53	3.87	16.19	3.87	11.85	3.87
1375.00:	23.19	4.80	26.57	4.80	23.19	4.80	19.80	4.80	16.42	4.80	13.03	4.80
1345.00:	21.90	4.34	24.87	4.46	21.90	4.34	18.93	4.22	15.95	4.10	12.98	3.98
1315.00:	17.76	12.15	19.99	13.42	17.76	12.15	15.52	10.87	13.29	9.59	11.06	8.31
1285.00:	16.77	13.11	18.91	14.49	16.77	13.11	14.63	14.14	12.49	10.35	10.36	8.97
1255.00:	16.26	14.40	18.39	15.93	16.26	14.40	12.87	12.02	11.33	9.90	9.80	

**** WARNING ****
THESE TABLES ASSUME THE LOWEST CONCRETE TEMPERATURES OCCUR IN FEBRUARY AND THE HIGHEST CONCRETE TEMPERATURES OCCUR IN AUGUST. SOME ADJUSTMENTS MAY BE NECESSARY BASED UPON * SITE SPECIFIC* CONDITIONS.

ADAS TEMPERATURE INPUT BY MONTH

ADAS TEMPERATURE INPUT BY MONTH		USUAL CONDITIONS, AIR ON BOTH FACES												CLOSURE TEMPERATURE = 45.00 F	
		JAN		FEB		MAR		APR		MAY		JUN			
ELEV	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM
1470.00	28	4.55	-7.33	4.55	28	4.55	7.88	4.55	15.49	4.55	23.09	4.55	23.09	4.55	
1435.00	4.54	3.31	-1.16	3.31	4.54	3.31	10.24	3.31	15.94	3.31	21.64	3.31	21.64	3.31	
1405.00	7.52	3.87	3.18	3.87	7.52	3.87	11.85	3.87	16.19	3.87	20.53	3.87	20.53	3.87	
1375.00	9.65	4.80	6.26	4.80	9.65	4.80	13.03	4.80	16.42	4.80	19.80	4.80	19.80	4.80	
1345.00	10.54	5.62	7.51	5.62	10.54	5.62	13.57	5.62	16.60	5.62	19.63	5.62	19.63	5.62	
1315.00	10.85	5.98	7.98	5.98	10.85	5.98	13.72	5.98	16.59	5.98	19.46	5.98	19.46	5.98	
1285.00	10.70	5.28	7.87	5.28	10.70	5.28	13.52	5.28	16.25	5.28	19.18	5.28	19.18	5.28	
1255.00	10.56	5.41	7.67	5.41	10.56	5.41	13.45	5.41	16.33	5.41	19.22	5.41	19.22	5.41	

ADAS TEMPERATURE INPUT BY MONTH

ADAS TEMPERATURE INPUT BY MONTH		USUAL CONDITIONS, AIR ON BOTH FACES												CLOSURE TEMPERATURE = 45.00 F	
		JUL		AUG		SEP		OCT		NOV		DEC			
ELEV	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM
1470.00	30.69	4.55	38.30	4.55	30.69	4.55	27.35	3.31	21.64	3.31	15.94	3.31	10.24	3.31	4.55
1435.00	27.35	3.31	33.05	3.31	29.21	3.87	24.87	3.87	20.53	3.87	16.19	3.87	11.85	3.87	3.87
1405.00	24.87	3.87	23.19	4.80	26.57	4.80	23.19	4.80	19.80	4.80	16.42	4.80	13.03	4.80	4.80
1375.00	22.66	5.62	25.69	5.62	22.66	5.62	19.63	5.62	16.60	5.62	13.57	5.62	13.57	5.62	5.62
1345.00	22.33	5.98	25.20	5.98	22.33	5.98	19.46	5.98	16.59	5.98	13.72	5.98	13.72	5.98	5.98
1315.00	22.00	5.28	24.83	5.28	22.00	5.28	19.18	5.28	16.35	5.28	13.52	5.28	13.52	5.28	5.28
1285.00	22.11	5.41	25.00	5.41	22.11	5.41	19.22	5.41	16.33	5.41	13.45	5.41	13.45	5.41	5.41

*** WARNING ***
THESE TABLES ASSUME THE LOWEST CONCRETE TEMPERATURES OCCUR IN FEBRUARY AND THE HIGHEST CONCRETE TEMPERATURES OCCUR IN AUGUST. SOME ADJUSTMENTS MAY BE NECESSARY BASED UPON "SITE SPECIFIC" CONDITIONS.

TABLE 9-4
MEAN CONDITIONS, AIR DS FACE / WATER US FACE CLOSURE TEMPERATURE = 45.0 F

ADSA'S TEMPERATURE INPUT BY MONTH		MEAN CONDITIONS, AIR DS FACE / WATER US FACE CLOSURE TEMPERATURE = 45.0 F											
		JAN	FEB	MAR	APR	MAY	JUN	JUL	SEP	OCT	NOV	DEC	
ELEV	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	
1470.00:	1.79	4.55	-5.23	4.55	1.79	4.55	8.81	4.55	15.83	4.55	22.85	4.55	
1435.00:	5.36	3.31	-0.02	3.31	5.36	3.31	10.75	3.31	16.13	3.31	21.51	3.31	
1405.00:	8.15	3.37	-4.06	3.87	8.15	3.87	12.24	3.87	16.34	3.87	20.43	3.87	
1375.00:	10.18	4.80	7.00	4.80	10.18	4.80	13.36	4.80	16.54	4.80	19.72	4.80	
1345.00:	10.26	4.35	7.38	4.43	10.26	4.25	13.13	4.28	16.01	4.21	18.89	4.14	
1315.00:	9.06	7.50	6.92	6.41	9.06	7.50	11.20	8.60	13.34	9.70	15.49	10.79	
1285.00:	8.45	8.05	6.40	6.85	8.45	8.05	10.50	9.25	12.55	10.45	14.60	11.65	
1255.00:	8.01	8.74	5.98	7.39	8.01	8.74	10.04	10.09	12.07	11.44	14.10	12.79	

TABLE 9-4
MEAN CONDITIONS, AIR DS FACE / WATER US FACE CLOSURE TEMPERATURE = 45.0 F

ADSA'S TEMPERATURE INPUT BY MONTH		MEAN CONDITIONS, AIR DS FACE / WATER US FACE CLOSURE TEMPERATURE = 45.0 F											
		JUL	AUG	SEP	OCT	NOV	DEC	JUL	AUG	SEP	OCT	NOV	DEC
ELEV	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	
1470.00:	29.87	4.55	36.89	4.55	29.87	4.55	22.85	4.55	15.83	4.55	8.81	4.55	
1435.00:	26.90	3.31	32.28	3.31	26.90	3.31	21.51	3.31	16.13	3.31	10.75	3.31	
1405.00:	24.52	3.87	28.61	3.87	24.52	3.87	20.43	3.87	16.34	3.87	12.24	3.87	
1375.00:	22.89	4.80	26.07	4.80	22.89	4.80	19.72	4.80	16.54	4.80	13.36	4.80	
1345.00:	21.76	4.07	24.64	4.00	21.76	4.07	18.89	4.14	16.01	4.21	13.13	4.28	
1315.00:	17.63	11.39	19.77	12.99	17.63	11.89	15.49	10.79	13.34	9.70	11.20	8.60	
1285.00:	16.64	12.85	18.69	14.05	16.64	12.85	14.60	11.65	12.55	10.45	10.50	9.25	
1255.00:	16.13	14.14	18.17	15.49	16.13	14.14	14.10	12.79	12.07	11.44	10.04	10.09	

*** WARNING ***
THESE TABLES ASSUME THE LOWEST CONCRETE TEMPERATURES OCCUR IN FEBRUARY AND THE HIGHEST CONCRETE TEMPERATURES OCCUR IN AUGUST. SOME ADJUSTMENTS MAY BE NECESSARY BASED UPON SITE SPECIFIC CONDITIONS.

ADDS TEMPERATURE INPUT BY MONTH		MEAN CONDITIONS, AIR ON BOTH FACES		CLOSURE TEMPERATURE = 45.00 F	
		JAN FEB MAR APR MAY JUN		ELEV	
		AVG AIR = 35.0 F: AVG AIR = 38.8 F: AVG AIR = 48.0 F: AVG AIR = 53.0 F: AVG AIR = 69.7 F: AVG AIR = 74.2 F		ELEV	
UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR
1470.00	1.79	4.55	-5.23	4.55	1.79
1435.00	5.36	3.31	-0.02	3.31	5.36
1400.00	8.15	3.87	4.06	3.87	8.15
1375.00	10.18	4.80	7.00	4.80	10.18
1350.00	11.03	5.62	8.19	5.62	11.03
1345.00	11.32	5.98	8.63	5.98	11.32
1325.00	11.16	5.28	8.51	5.28	11.16
1295.00	11.03	5.41	8.32	5.41	11.03

TABLE 9-5
CLOSURE TEMPERATURE = 45.00 F
ON BOTH FACES

TABLE 9-5 CLOSURE TEMPERATURE = 45.00 F
ON BOTH FACES

TABLE 10-1
Comparison of the μ and μ' Parameters of the Fe^{2+} -Bipy System

***** WARNING *****
THESE TABLES ASSUME THE LOWEST CONCRETE TEMPERATURES OCCUR IN FEBRUARY AND THE HIGHEST CONCRETE TEMPERATURES OCCUR IN AUGUST. SOME ADJUSTMENTS MAY BE NECESSARY BASED UPON SITE SPECIFIC CONDITIONS.

TABLE 10-2
USUAL CONDITIONS, AIR VS FACE / WATER VS FACE
CLOSURE TEMPERATURE = 50.0 F

JAN		FEB		MAR		APR		MAY		JUN	
ELEV		AVG AIR = 35.0 F		AVG AIR = 38.8 F		AVG AIR = 48.0 F		AVG AIR = 53.0 F		AVG AIR = 69.7 F	
UNIFORM : LINEAR		UNIFORM : LINEAR		UNIFORM : LINEAR		UNIFORM : LINEAR		UNIFORM : LINEAR		UNIFORM : LINEAR	
1470.00	-4.72	4.55	-12.33	-4.55	-4.72	4.55	-4.72	2.88	4.55	10.49	4.55
1435.00	-4.46	3.31	-6.16	3.31	-5.46	3.31	-5.24	3.31	10.94	3.31	16.64
1400.00	-2.52	3.87	-1.82	1.82	-2.52	3.87	-6.85	3.87	11.19	3.87	15.53
1375.00	4.65	4.80	1.26	4.80	4.65	4.80	8.03	4.80	11.48	4.80	14.80
1345.00	5.01	3.86	2.04	3.74	5.01	3.86	7.98	3.98	10.95	4.10	13.93
1325.00	3.83	1.04	1.60	5.76	3.83	7.04	6.06	8.31	8.29	9.59	10.87
1285.00	3.22	7.59	1.08	6.21	3.22	7.59	5.36	8.97	7.49	10.52	11.73
1255.00	2.77	8.27	6.74	2.77	2.77	8.27	4.90	9.80	7.02	11.33	9.14

ELEV	JUL			AUG			SEP			OCT			NOV			DEC			
	AVG AIR = 78.1 F;			AVG AIR = 78.2 F;			AVG AIR = 69.4 F;			AVG AIR = 53.8 F;			AVG AIR = 51.8 F;			AVG AIR = 43.0 F			
UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR	UNIFORM	LINEAR		
14470.00	25.69	:	4.55	:	33.30	:	4.55	:	25.69	:	4.55	:	10.49	:	4.55	:	2.88	:	4.55
14455.00	22.35	:	3.31	:	28.05	:	3.31	:	22.35	:	3.31	:	16.64	:	3.31	:	5.24	:	3.31
14450.00	19.87	:	3.87	:	24.21	:	3.87	:	19.87	:	3.87	:	15.53	:	3.87	:	11.19	:	3.87
13475.00	18.19	:	4.80	:	21.57	:	4.80	:	18.19	:	4.80	:	14.80	:	4.80	:	11.45	:	4.80
13455.00	16.90	:	4.34	:	19.87	:	4.46	:	16.90	:	4.34	:	13.93	:	4.22	:	10.52	:	4.10
13415.00	12.76	:	12.15	:	14.99	:	13.42	:	12.76	:	12.15	:	10.52	:	10.87	:	8.29	:	9.59
12285.00	11.77	:	13.11	:	13.91	:	14.49	:	11.77	:	13.11	:	9.63	:	11.73	:	7.49	:	10.35
12255.00	11.26	:	14.40	:	13.39	:	15.93	:	11.26	:	14.40	:	9.14	:	12.87	:	7.02	:	11.33

***** WARNING *****
THESE TABLES ASSUME THE LOWEST CONCRETE TEMPERATURES OCCUR IN FEBRUARY AND THE HIGHEST CONCRETE TEMPERATURES OCCUR IN AUGUST. SOME ADJUSTMENTS MAY BE NECESSARY BASED UPON "SITE SPECIFIC" CONDITIONS.

ADSA'S TEMPERATURE INPUT BY MONTH

ELEV	USUAL CONDITIONS, AIR ON BOTH FACES												CLOSURE TEMPERATURE = 50.00 F		
	JAN	FEB	MAR	APR	MAY	JUN	JUL	SEP	OCT	NOV	DEC	Avg Air			
1470.00:	-4.72	4.55	-12.33	4.55	-4.72	4.55	-4.72	2.88	4.55	10.49	4.55	18.09	4.55		
1435.00:	-4.6	3.31	-6.16	3.31	-4.6	3.31	-4.6	5.24	3.31	10.94	3.31	16.64	3.31		
1405.00:	2.52	3.87	-1.82	3.87	2.52	3.87	2.52	6.85	3.87	11.19	3.87	15.53	3.87		
1375.00:	4.65	4.80	1.26	4.80	4.65	4.80	4.65	8.03	4.80	11.42	4.80	14.80	4.80		
1345.00:	5.54	5.62	2.51	5.62	5.54	5.62	5.54	8.57	5.62	11.60	5.62	14.63	5.62		
1315.00:	5.85	5.98	2.98	5.98	5.85	5.98	5.85	8.72	5.98	11.59	5.98	14.46	5.98		
1285.00:	5.70	5.28	2.87	5.28	5.70	5.28	5.70	8.52	5.28	11.35	5.28	14.18	5.28		
1255.00:	5.56	5.41	2.67	5.41	5.56	5.41	5.41	8.45	5.41	11.33	5.41	14.22	5.41		

TABLE 10-3
ADSA'S TEMPERATURE INPUT BY MONTH

ELEV	USUAL CONDITIONS, AIR ON BOTH FACES												CLOSURE TEMPERATURE = 50.00 F		
	JAN	FEB	MAR	APR	MAY	JUN	JUL	SEP	OCT	NOV	DEC	Avg Air			
1470.00:	25.69	4.55	33.30	4.55	25.69	4.55	25.69	18.09	4.55	10.49	4.55	2.88	4.55		
1435.00:	22.35	3.31	28.05	3.31	22.35	3.31	22.35	16.64	3.31	10.94	3.31	5.24	3.31		
1405.00:	19.87	3.87	24.21	3.87	19.87	3.87	19.87	15.53	3.87	11.19	3.87	6.85	3.87		
1375.00:	18.19	4.80	21.57	4.80	18.19	4.80	18.19	14.80	4.80	11.42	4.80	8.03	4.80		
1345.00:	17.66	5.62	20.69	5.62	17.66	5.62	17.66	14.63	5.62	11.60	5.62	8.57	5.62		
1315.00:	17.33	5.98	20.20	5.98	17.33	5.98	17.33	14.46	5.98	11.59	5.98	8.72	5.98		
1285.00:	17.00	5.28	19.83	5.28	17.00	5.28	17.00	14.18	5.28	11.35	5.28	8.52	5.28		
1255.00:	17.11	5.41	20.00	5.41	17.11	5.41	17.11	14.22	5.41	11.33	5.41	8.45	5.41		

TABLE 10-3
ADSA'S TEMPERATURE INPUT BY MONTH

ELEV	USUAL CONDITIONS, AIR ON BOTH FACES												CLOSURE TEMPERATURE = 50.00 F		
	JAN	FEB	MAR	APR	MAY	JUN	JUL	SEP	OCT	NOV	DEC	Avg Air			
1470.00:	25.69	4.55	33.30	4.55	25.69	4.55	25.69	18.09	4.55	10.49	4.55	2.88	4.55		
1435.00:	22.35	3.31	28.05	3.31	22.35	3.31	22.35	16.64	3.31	10.94	3.31	5.24	3.31		
1405.00:	19.87	3.87	24.21	3.87	19.87	3.87	19.87	15.53	3.87	11.19	3.87	6.85	3.87		
1375.00:	18.19	4.80	21.57	4.80	18.19	4.80	18.19	14.80	4.80	11.42	4.80	8.03	4.80		
1345.00:	17.66	5.62	20.69	5.62	17.66	5.62	17.66	14.63	5.62	11.60	5.62	8.57	5.62		
1315.00:	17.33	5.98	20.20	5.98	17.33	5.98	17.33	14.46	5.98	11.59	5.98	8.72	5.98		
1285.00:	17.00	5.28	19.83	5.28	17.00	5.28	17.00	14.18	5.28	11.35	5.28	8.52	5.28		
1255.00:	17.11	5.41	20.00	5.41	17.11	5.41	17.11	14.22	5.41	11.33	5.41	8.45	5.41		

*** WARNING ***
THESE TABLES ASSUME THE LOWEST CONCRETE TEMPERATURES OCCUR IN FEBRUARY AND THE HIGHEST CONCRETE TEMPERATURES OCCUR IN AUGUST.
SOME ADJUSTMENTS MAY BE NECESSARY BASED UPON "SITE SPECIFIC" CONDITIONS.

ADSAS TEMPERATURE INPUT BY MONTH MEAN CONDITIONS, AIR DS FACE / WATER US FACE CLOSURE TEMPERATURE = 50.0 F

ELEV	JAN		FEB		MAR		APR		MAY		JUN	
	AVG AIR = 35.0 F	Avg Air = 38.8 F	AVG AIR = 48.0 F	Avg Air = 53.0 F	AVG AIR = 69.7 F	Avg Air = 74.2 F	AVG AIR = 53.0 F	Avg Air = 69.7 F	AVG AIR = 74.2 F			
1470.00	-3.21	4.55	-10.23	4.55	-3.21	4.55	3.81	4.55	10.83	4.55	17.85	4.55
1435.00	.36	3.31	-5.02	3.31	.36	3.31	5.75	3.31	11.13	3.31	16.51	3.31
1405.00	3.15	3.87	-.94	3.87	3.15	3.87	7.24	3.87	11.34	3.87	15.43	3.87
1375.00	5.18	4.80	2.00	4.80	5.18	4.80	8.36	4.80	11.54	4.80	14.72	4.80
1345.00	5.26	4.35	2.38	4.43	5.26	4.35	8.13	4.28	11.01	4.21	13.89	4.14
1315.00	4.06	7.50	1.92	6.41	4.06	7.50	6.20	8.60	8.34	9.70	10.49	10.79
1285.00	3.45	8.05	1.40	6.85	3.45	8.05	5.50	9.25	7.55	10.45	9.60	11.65
1255.00	3.01	8.74	.98	7.39	3.01	8.74	5.04	10.09	7.07	11.44	9.10	12.79

ADSAS TEMPERATURE INPUT BY MONTH MEAN CONDITIONS, AIR DS FACE / WATER US FACE CLOSURE TEMPERATURE = 50.0 F

ELEV	JUL		AUG		SEP		OCT		NOV		DEC	
	AVG AIR = 78.1 F	Avg Air = 78.2 F	AVG AIR = 69.4 F	Avg Air = 69.4 F	AVG AIR = 53.8 F	Avg Air = 53.8 F	AVG AIR = 51.8 F	Avg Air = 51.8 F	AVG AIR = 43.0 F			
1470.00	24.87	4.55	31.89	4.55	24.87	4.55	17.85	4.55	10.83	4.55	3.81	4.55
1435.00	21.90	3.31	27.28	3.31	21.90	3.31	16.51	3.31	11.13	3.31	5.75	3.31
1405.00	19.52	3.87	23.61	3.87	19.52	3.87	15.43	3.87	11.34	3.87	7.24	3.87
1375.00	17.89	4.80	21.07	4.80	17.89	4.80	14.72	4.80	11.54	4.80	8.36	4.80
1345.00	16.76	4.07	19.64	4.00	16.76	4.07	13.89	4.14	11.01	4.21	8.13	4.28
1315.00	12.63	11.89	14.77	12.99	12.63	11.89	10.49	10.79	8.34	9.70	6.20	8.60
1285.00	11.64	12.85	13.69	14.05	11.64	12.85	9.60	11.65	7.55	10.45	5.50	9.25
1255.00	11.13	14.14	13.17	15.49	11.13	14.14	9.10	12.79	7.07	11.44	5.04	10.09

*** WARNING ***

THESE TABLES ASSUME THE LOWEST CONCRETE TEMPERATURES OCCUR IN FEBRUARY AND THE HIGHEST CONCRETE TEMPERATURES OCCUR IN AUGUST. SOME ADJUSTMENTS MAY BE NECESSARY BASED UPON "SITE SPECIFIC" CONDITIONS.

ADSA'S TEMPERATURE INPUT BY MONTH

		MEAN CONDITIONS, AIR ON BOTH FACES												CLOSURE TEMPERATURE = 50.00 F
		JAN	FEB	MAR	APR	MAY	JUN	JUL	SEP	OCT	NOV	DEC		
ELEV		AVG AIR = 35.0 F: AVG AIR = 38.8 F: AVG AIR = 48.0 F: AVG AIR = 53.0 F: AVG AIR = 69.7 F: AVG AIR = 74.2 F	UNIFORM : LINEAR : UNIFORM : LINEAR											
1470.00:	-3.21	4.55	-10.23	4.55	-3.21	4.55	3.81	4.55	10.83	4.55	17.85	4.55		
1435.00:	-3.16	3.31	-5.02	3.31	3.36	3.31	5.75	3.31	11.13	3.31	16.51	3.31		
1405.00:	3.15	3.87	-9.94	3.87	3.15	3.87	7.24	3.87	11.34	3.87	15.43	3.87		
1375.00:	5.18	4.80	2.00	4.80	5.18	4.80	8.36	4.80	11.54	4.80	14.72	4.80		
1345.00:	6.03	5.62	3.19	5.62	6.03	5.62	8.87	5.62	11.71	5.62	14.55	5.62		
1315.00:	6.32	5.98	3.63	5.98	6.32	5.98	9.01	5.98	11.70	5.98	14.39	5.98		
1285.00:	6.16	5.28	3.51	5.28	6.16	5.28	8.81	5.28	11.45	5.28	14.10	5.28		
1255.00:	6.03	5.41	3.32	5.41	6.03	5.41	8.73	5.41	11.44	5.41	14.15	5.41		

TABLE 10-5
ADSA'S TEMPERATURE INPUT BY MONTH

		MEAN CONDITIONS, AIR ON BOTH FACES												CLOSURE TEMPERATURE = 50.00 F
		JUL	AUG	SEP	OCT	NOV	DEC	JUL	AUG	SEP	OCT	NOV	DEC	
ELEV		AVG AIR = 78.1 F: AVG AIR = 78.2 F: AVG AIR = 69.4 F: AVG AIR = 53.8 F: AVG AIR = 51.8 F: AVG AIR = 43.0 F	UNIFORM : LINEAR : UNIFORM : LINEAR											
1470.00:	24.87	4.55	31.89	4.55	24.87	4.55	17.85	4.55	10.83	4.55	3.81	4.55		
1435.00:	21.90	3.31	27.28	3.31	21.90	3.31	16.51	3.31	11.13	3.31	5.75	3.31		
1405.00:	19.52	3.87	23.61	3.87	19.52	3.87	15.43	3.87	11.34	3.87	7.24	3.87		
1375.00:	17.89	4.80	21.07	4.80	17.89	4.80	14.72	4.80	11.54	4.80	8.36	4.80		
1345.00:	17.39	5.62	20.23	5.62	17.39	5.62	14.55	5.62	11.71	5.62	8.87	5.62		
1315.00:	17.08	5.98	19.77	5.98	17.08	5.98	14.39	5.98	11.70	5.98	9.01	5.98		
1285.00:	16.75	5.28	19.40	5.28	16.75	5.28	14.10	5.28	11.45	5.28	8.81	5.28		
1255.00:	16.85	5.41	19.56	5.41	16.85	5.41	14.15	5.41	11.44	5.41	8.73	5.41		

REPORT DOCUMENTATION PAGE			Form Approved OMB No. 0704-0188
<p>Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.</p>			
1. AGENCY USE ONLY (Leave blank)	2. REPORT DATE	3. REPORT TYPE AND DATES COVERED	
	September 1995	Final report	
4. TITLE AND SUBTITLE		5. FUNDING NUMBERS	
User's Guide for Computer Program TEMPER (X8305)			
6. AUTHOR(S)			
Terry West			
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)		8. PERFORMING ORGANIZATION REPORT NUMBER	
Federal Energy Regulatory Commission Atlanta Regional Office 3125 Presidential Parkway, Suite 300 Atlanta, GA 30340			
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)		10. SPONSORING/MONITORING AGENCY REPORT NUMBER	
U.S. Army Corps of Engineers, Washington, DC 20314-1000 U.S. Army Engineer Waterways Experiment Station 3909 Halls Ferry Road Vicksburg, MS 39180-6199		Instruction Report ITL-95-2	
11. SUPPLEMENTARY NOTES			
Available from National Technical Information Service, 5285 Port Royal Road, Springfield, VA 22161.			
12a. DISTRIBUTION/AVAILABILITY STATEMENT		12b. DISTRIBUTION CODE	
Approved for public release; distribution is unlimited.			
13. ABSTRACT (Maximum 200 words)			
<p>This manual documents the computer program TEMPER (X8305) which estimates, using classical heat flow methods, the uniform and linear temperature distributions in arch dams. The program uses the theoretical methods described in "Control of Cracking in Mass Concrete Structures" by the U.S. Department of the Interior, Bureau of Reclamation.</p>			
14. SUBJECT TERMS		15. NUMBER OF PAGES	
Arch dams Temperature distribution		49	
		16. PRICE CODE	
17. SECURITY CLASSIFICATION OF REPORT	18. SECURITY CLASSIFICATION OF THIS PAGE	19. SECURITY CLASSIFICATION OF ABSTRACT	20. LIMITATION OF ABSTRACT
UNCLASSIFIED	UNCLASSIFIED		